

# Recommended Next Features - Implementation Guide

## Top 5 Features to Add Next

Based on typical astrophotography workflows and missing critical features:

---

### #1: Auto-Focus Routine ★★ ★

**Priority:** CRITICAL

**Effort:** 3-5 days

**Impact:** Massive quality improvement

#### Why You Need This:

- Focus drifts with temperature (even 1°C affects focus)
- Manual focusing wastes time and isn't repeatable
- Required for unattended imaging sessions
- Filter changes require refocus

#### What It Does:

1. Takes series of exposures at different focus positions
2. Measures star sharpness (HFR - Half-Flux Radius)
3. Finds optimal focus position (minimum HFR)
4. Returns focuser to best position

#### Implementation Outline:

python

*# autofocus.py - New file*

import numpy as np

from scipy import ndimage

class AutoFocus:

def \_\_init\_\_(self, camera, focuser):

self.camera = camera

self.focuser = focuser

def calculate\_hfr(self, image):

"""

Calculate Half-Flux Radius of stars

Lower HFR = sharper stars = better focus

"""

*# 1. Background subtraction*

background = np.median(image)

image\_sub = image - background

*# 2. Find stars (simple threshold)*

threshold = np.mean(image\_sub) + 3 \* np.std(image\_sub)

stars = image\_sub > threshold

*# 3. Label connected components*

labeled, num\_stars = ndimage.label(stars)

if num\_stars == 0:

return None

*# 4. Calculate HFR for each star*

hfrs = []

for i in range(1, num\_stars + 1):

star\_mask = labeled == i

*# Skip if too small/large*

star\_pixels = np.sum(star\_mask)

if star\_pixels < 10 or star\_pixels > 1000:

continue

*# Find centroid*

y, x = np.where(star\_mask)

flux = image\_sub[star\_mask]

cx = np.sum(x \* flux) / np.sum(flux)

cy = np.sum(y \* flux) / np.sum(flux)

*# Calculate HFR*

distances = np.sqrt((x - cx)\*\*2 + (y - cy)\*\*2)

```

sorted_flux = np.sort(flux)[::-1]
half_flux = np.sum(sorted_flux) / 2

cumsum = 0
for j, f in enumerate(sorted_flux):
    cumsum += f
    if cumsum >= half_flux:
        hfr = distances[j]
        hfrs.append(hfr)
        break

# Return median HFR
return np.median(hfrs) if hfrs else None

def run_vcurve(self, exposure_time=2.0,
               initial_position=None,
               step_size=500,
               num_steps=9):
    """
    V-curve autofocus: sample positions around current focus
    """
    # Get starting position
    if initial_position is None:
        initial_position = self.focuser.get_position()

    # Calculate sample positions (centered on initial)
    half_steps = num_steps // 2
    positions = [
        initial_position + (i - half_steps) * step_size
        for i in range(num_steps)
    ]

    # Ensure within bounds
    positions = [
        max(0, min(p, self.focuser.max_position))
        for p in positions
    ]

    results = []

    print(f"Starting V-curve autofocus...")
    print(f"  Initial: {initial_position}")
    print(f"  Range: {positions[0]} to {positions[-1]}")
    print(f"  Step: {step_size}")

    for i, pos in enumerate(positions):
        print(f"\n[{i+1}/{num_steps}] Testing position {pos}...")

        # Move focuser
        self.focuser.move_to(pos)

```

```
# Take exposure
```

```
self.camera.start_exposure(exposure_time, light=True)
```

```
# Wait for completion
```

```
while self.camera.camera_state != 3: # ImageReady  
    time.sleep(0.1)
```

```
# Get image
```

```
image = self.camera.get_image_array()
```

```
# Calculate HFR
```

```
hfr = self.calculate_hfr(image)
```

```
if hfr is not None:
```

```
    results.append((pos, hfr))
```

```
    print(f" HFR: {hfr:.2f} pixels")
```

```
else:
```

```
    print(f" HFR: No stars detected")
```

```
if len(results) < 3:
```

```
    print("✗ Insufficient data points for autofocus")
```

```
    return None
```

```
# Find best position (minimum HFR)
```

```
results.sort(key=lambda x: x[1])
```

```
best_position, best_hfr = results[0]
```

```
# Optional: Fit parabola for sub-step accuracy
```

```
# (implement if needed for higher precision)
```

```
# Move to best position
```

```
print(f"\n✓ Best focus: {best_position} (HFR: {best_hfr:.2f})")
```

```
self.focuser.move_to(best_position)
```

```
return best_position
```

```
def auto_focus(self, exposure_time=2.0, coarse=True, fine=True):
```

```
    """
```

```
    Two-stage autofocus: coarse then fine
```

```
    """
```

```
    current_pos = self.focuser.get_position()
```

```
# Coarse focus (large steps)
```

```
if coarse:
```

```
    print("\n=== Coarse Focus ===")
```

```
    coarse_pos = self.run_vcurve(  
        exposure_time=exposure_time,
```

```
        initial_position=current_pos,
```

```
        # ... (rest of the function code)
```

```

        step_size=1000,
        num_steps=7
    )
    current_pos = coarse_pos or current_pos

    # Fine focus (small steps)
    if fine:
        print("\n=== Fine Focus ===")
        fine_pos = self.run_vcurve(
            exposure_time=exposure_time,
            initial_position=current_pos,
            step_size=100,
            num_steps=9
        )
        current_pos = fine_pos or current_pos

    return current_pos

```

## Integration with main.py:

```

python

# Add route for autofocus
@app.route('/api/v1/focuser/0/autofocus', methods=['PUT'])
def focuser_autofocus():
    """Run autofocus routine"""
    if not focuser or not camera_zwo:
        return helpers.alpaca_error(1024, "Focuser or camera not available")

    exposure = helpers.get_form_value('ExposureTime', 2.0, float)

    from autofocus import AutoFocus
    af = AutoFocus(camera_zwo, focuser)

    # Run in background thread
    def run():
        af.auto_focus(exposure_time=exposure)

    import threading
    thread = threading.Thread(target=run, daemon=True)
    thread.start()

    return helpers.alpaca_response()

```

## Testing:

```
bash
```

```
# Test autofocus
```

```
curl -X PUT "http://localhost:5555/api/v1/focuser/0/autofocus" \  
-d "ExposureTime=2.0"
```

---

## #2: Improved Slewing Detection ★★ ★

**Priority:** HIGH

**Effort:** 1 day

**Impact:** Reliable slew completion

### Why You Need This:

- OnStepX doesn't provide reliable IsSlewing status
- Clients may proceed before slew completes
- Causes plate solve failures and tracking issues

### Implementation:

python

*# In telescope.py*

```
def is_slewing(self):
    """
    Enhanced slewing detection using position stability
    """
    if not self.is_connected:
        return False

    # If we never started a slew, not slewing
    if not hasattr(self, '_slewing_target'):
        return False

    # Get current position
    current_ra = self.get_right_ascension()
    current_dec = self.get_declination()

    # Check if close to target (within 1 arcminute)
    ra_diff = abs(current_ra - self._slewing_target[0]) * 15 * 60 # to arcmin
    dec_diff = abs(current_dec - self._slewing_target[1]) * 60 # to arcmin

    threshold = 1.0 # 1 arcminute

    if ra_diff < threshold and dec_diff < threshold:
        # Close to target, check stability
        if not hasattr(self, '_stable_since'):
            self._stable_since = time.time()
            self._last_position = (current_ra, current_dec)
            return True

        # Check if position has been stable
        stable_time = time.time() - self._stable_since

        # Has position moved?
        last_ra_diff = abs(current_ra - self._last_position[0]) * 15 * 60
        last_dec_diff = abs(current_dec - self._last_position[1]) * 60

        if last_ra_diff > 0.1 or last_dec_diff > 0.1:
            # Still moving, reset stability timer
            self._stable_since = time.time()
            self._last_position = (current_ra, current_dec)
            return True

        # Position stable for 2 seconds = slew complete
        if stable_time > 2.0:
            del self._slewing_target
            del self._stable_since
```

```

        return False

    return True

# Not close to target yet
    return True

def slew_to_coords(self, ra_hours, dec_degrees):
    """Slew to RA/Dec with target tracking"""
    self.slewing_target = (ra_hours, dec_degrees)

    ra_str = helpers.format_ra_hours(ra_hours)
    dec_str = helpers.format_dec_degrees(dec_degrees).replace(':', '*')

    self.send_command(f'Sr{ra_str}#')
    self.send_command(f'Sd{dec_str}#')

    response = self.send_command(':MS#')
    return response == '0'

```

### #3: Dithering Support ★★

**Priority:** MEDIUM-HIGH

**Effort:** 2 days

**Impact:** Better image quality

#### Why You Need This:

- Eliminates hot pixels and pattern noise
- Standard practice in astrophotography
- Simple but very effective

#### Implementation:



python

*# dithering.py - New file*

import random

import math

class Dithering:

def \_\_init\_\_(self, telescope):

self.telescope = telescope

self.original\_ra = None

self.original\_dec = None

def dither(self, radius\_pixels=5, pixel\_scale=1.0):

"""

Dither telescope by random offset

Args:

radius\_pixels: Max dither radius in pixels

pixel\_scale: Arcseconds per pixel

Returns:

(offset\_ra, offset\_dec) in arcseconds

"""

*# Save original position on first dither*

if self.original\_ra is None:

self.original\_ra = self.telescope.get\_right\_ascension()

self.original\_dec = self.telescope.get\_declination()

*# Random angle and radius*

angle = random.uniform(0, 2 \* math.pi)

radius = random.uniform(0, radius\_pixels) \* pixel\_scale

*# Convert to RA/Dec offsets (arcseconds)*

offset\_ra = radius \* math.cos(angle)

offset\_dec = radius \* math.sin(angle)

*# Convert arcseconds to degrees*

offset\_ra\_deg = offset\_ra / 3600.0

offset\_dec\_deg = offset\_dec / 3600.0

*# Convert RA offset to hours (accounting for declination)*

dec\_rad = math.radians(self.original\_dec)

offset\_ra\_hours = offset\_ra\_deg / (15.0 \* math.cos(dec\_rad))

offset\_dec\_hours = offset\_dec\_deg / 15.0

*# Calculate new position*

new\_ra = self.original\_ra + offset\_ra\_hours

new\_dec = self.original\_dec + offset\_dec\_hours

```
# Slew to dithered position
```

```
print(f"Dithering: RA={offset_ra:.1f}\ Dec={offset_dec:.1f}\")
```

```
self.telescope.slew_to_coords(new_ra, new_dec)
```

```
return (offset_ra, offset_dec)
```

```
def return_to_center(self):
```

```
    """Return to original undithered position"""
```

```
    if self.original_ra is not None:
```

```
        print("Returning to original position")
```

```
        self.telescope.slew_to_coords(
```

```
            self.original_ra,
```

```
            self.original_dec
```

```
        )
```

```
        self.original_ra = None
```

```
        self.original_dec = None
```

## Usage in N.I.N.A.:

Configure dithering in sequence:

- After every N exposures
- Radius: 3-10 pixels
- Settle time: 5-10 seconds

---

## #4: Simultaneous Camera Exposures ★★

**Priority:** MEDIUM

**Effort:** 2-3 days

**Impact:** Enable guiding while imaging

### Why You Need This:

- Guide camera needs to expose during imaging
- Currently cameras take turns
- Required for autoguiding

### Implementation:

python

*# In camera\_zwo.py and camera\_touptek.py*

*# Make exposure async with threading*

```
def start_exposure(self, duration, light=True):
    """Start asynchronous exposure"""
    if self.camera_state != 0: # Idle
        raise Exception("Camera busy")

    self.camera_state = 1 # Exposing
    self.exposure_start = time.time()
    self.exposure_duration = duration

    def exposure_thread():
        try:
            # Start hardware exposure
            self._start_hardware_exposure(duration, light)

            # Wait for completion
            while not self._is_exposure_complete():
                time.sleep(0.1)

            # Download image
            self._download_image()

            self.camera_state = 3 # ImageReady
        except Exception as e:
            print(f"Exposure error: {e}")
            self.camera_state = 0 # Idle

    import threading
    self.exposure_thread = threading.Thread(
        target=exposure_thread,
        daemon=True
    )
    self.exposure_thread.start()
```

Now both cameras can expose simultaneously!

---

## #5: Meridian Flip Handling ★★

**Priority:** MEDIUM

**Effort:** 2-3 days

**Impact:** All-night imaging

**Why You Need This:**

- Targets cross meridian during long sessions
- Must flip to prevent cable wrap
- Requires pause, flip, resync, resume

## Implementation:

```
python
# meridian_flip.py - New file

class MeridianFlipHandler:
    def __init__(self, telescope):
        self.telescope = telescope
        self.flip_threshold = 0.5 # Hours past meridian

    def should_flip(self):
        """Check if meridian flip needed"""
        ra = self.telescope.get_right_ascension()
        lst = self.telescope.get_sidereal_time()

        hour_angle = lst - ra
        if hour_angle < 0:
            hour_angle += 24

        # Should flip if > 12 + threshold hours
        return hour_angle > (12 + self.flip_threshold)

    def perform_flip(self, target_ra, target_dec):
        """Execute meridian flip"""
        print("Performing meridian flip...")

        # 1. Stop any ongoing operations
        self.telescope.stop_slew()

        # 2. Slew to target on opposite pier side
        # OnStepX handles this automatically
        self.telescope.slew_to_coords(target_ra, target_dec)

        # 3. Wait for slew completion
        while self.telescope.is_slewing():
            time.sleep(1)

        print("✓ Meridian flip complete")

        # 4. Caller should plate solve and recalibrate guiding
        return True
```

## Integration with N.I.N.A.:

N.I.N.A. handles meridian flips automatically when using Alpaca telescope. Your telescope just needs reliable IsSlewing and slew commands - which you have!

---

## **Implementation Checklist**

### **Phase 1: Critical (1 week)**

- ☐ Improved slewing detection (1 day)
- ☐ Simultaneous exposures (2-3 days)
- ☐ Auto-focus routine (3-5 days)

### **Phase 2: Workflow (1 week)**

- ☐ Dithering support (2 days)
- ☐ Meridian flip handling (2-3 days)
- ☐ Error recovery (3 days)

### **Phase 3: Integration (1 week)**






- ☐ Plate solving integration (3-4 days)
  - ☐ Configuration persistence (1-2 days)
  - ☐ Enhanced logging (2 days)
- 

## **Quick Wins (< 1 Day Each)**

- 1. Configuration Persistence** - Save filter names/offsets
  - 2. Enhanced Logging** - Structured JSON logs
  - 3. Performance Metrics** - Track exposure timing
  - 4. Backup System** - Auto-backup config files
- 

## **What You Already Have**

**Good news - these are DONE:**

-  **Pulse Guiding** - PHD2 ready!
  -  **UDP Discovery** - Auto-discovery works
  -  **Filter Wheel** - With focus offsets
  -  **Focuser** - With temperature monitoring
  -  **Network/USB** - Flexible connection
- 

## **Recommended Action Plan**

## **Week 1: Auto-Focus**

- Most impactful feature
- Uses existing hardware
- Immediate quality improvement

## **Week 2: Slewing + Simultaneous Exposures**

- Fixes OnStepX limitation
- Enables proper guiding

## **Week 3: Dithering + Meridian Flip**

- Standard workflow features
- N.I.N.A. integration

**Result:** Fully automated, professional imaging setup! 🌟

---

**Start with auto-focus - you'll see the difference immediately in your images!**